



ST Voice Switch Wall Mount Bracket Kit

Quick Install Guide



Powering connections

Mitel Networks Corporation
4000 Innovation Drive
Kanata, Ontario K2K 3K1
Canada
+1 613-592-2122

Introduction and Installing Brackets

The ST Voice Switch Wall Mount Bracket Kit Contains:

- One ST Voice Switch Wall Mount Bracket.
- Three drywall anchors for attaching the ST Voice Switch Wall Mount Bracket to drywall.
- Three Phillips sheet metal screws for use with drywall anchors.
- Three Phillips round head wood screws for attaching ST Voice Switch Wall Mount Bracket to a plywood wall.

About the ST Voice Switch Wall Mount Bracket

The ST Voice Switch Wall Mount Bracket is an accessory that is used to mount one half-width Mitel ST Voice Switch on a wall. The front of the voice switch will face to the right when mounted on the wall. This wall mount bracket is designed for use with the following devices:

- Mitel Voice Switch ST50A
- Mitel Voice Switch ST100A
- Mitel Voice Switch ST100DA
- Mitel Voice Switch ST200
- Mitel Voice Switch ST500
- Mitel Voice Switch ST1D
- Mitel Voice Switch ST2D



WARNING: To prevent overheating and fire hazard, do not use the Rack Mount Dual Switch Tray to wall mount the ST Voice Switches.


Installation Equipment

To install the Mitel Voice Switch, you need the following tool(s):


- #1 Phillips screwdriver

Preparing a Plywood Sheet for ST Voice Switch Wall Mount Bracket

1. Securely anchor a sheet of plywood to the wall and underlying structure.
 - The minimum wall area is 17.50 inches (444 mm) by 14 inches (355 mm).
 - Minimum plywood size is 14.50 inches (368 mm) by 11 inches (279 mm).
 - Minimum plywood thickness is 0.5 inch (13 mm)
2. Punch three pilot marks in the plywood using the wall mount as a template.
3. At the top pilot mark, insert one round head wood screw partially into the plywood. Leave 1/8 inch (3.2 mm) of the screw shank exposed.




Preparing the Installation Surface



Preparing Drywall for ST Voice Switch Wall Mount Bracket

1. The minimum wall area required for mounting a ST Voice Switch Wall Mount Bracket is 17.50 inches (444 mm) by 14 inches (355 mm).
Minimum drywall thickness: 3/8 inch (10 mm).
Maximum drywall thickness: 5/8 inch (16 mm).
2. Punch three pilot marks using the wall mount as a template to determine the mark placement.
3. At each pilot mark, insert the screw-in drywall anchors flush to the drywall.
4. Insert one Phillips sheet metal screw at the top position partially into the drywall anchor. Leave 1/8 inch (3.2 mm) of the screw shank exposed.






Placing the ST Voice Switch Wall Mount Bracket on the Wall

1. Hang the empty ST Voice Switch Wall Mount Bracket over the Phillips sheet metal screw you inserted at the top position, and then tighten the screw to affix the bracket to the wall.
2. Install round head screws in the bottom positions to secure the bracket to the wall.

Mounting the Bracket and Specifications

Installing the ST Voice Switch into the ST Voice Switch Wall Mount Bracket

1. On the ST Voice Switch, remove the right side top cover screw, as shown in the image to the right.
2. Align the slots on the left side of the Mitel Voice Switch with the tabs on the bracket, slide the Mitel Voice Switch slots onto the tabs on the bracket, and then rotate the Mitel Voice Switch into the bracket.
3. Re-install the right side top cover screw to securely attach chassis to bracket.



ST Voice Switch Wall Mount Bracket Specifications

Feature	Specification
Dimensions	14-5/16 x 10-7/8 x 1-3/4 inches (363 x 277 x 44 mm)
Weight	2.7 lbs. (1.23 kg)

Vorbereitung der Installationsoberfläche

Das Wandmontagekit für den ST Voice Switch enthält:

- Einen ST Voice Switch-Wandmontageträger
- Drei Hohlraumdübel zum Befestigen des ST Voice Switch-Wandmontageträgers an einer Hohlwand
- Drei Kreuzschlitz-Metallschrauben zur Verwendung mit den Hohlraumdübeln
- Drei Rundkopf-Holzschrauben mit Kreuzschlitz zum Befestigen des ST Voice Switch-Wandmontageträgers an einer Sperrholzplatte.

Der ST Voice Switch-Wandmontageträger

Der ST Voice Switch-Wandmontageträger ist ein Zubehörteil, mit dem Sie einen Mittel ST Voice Switch halber Baugröße an einer Wand befestigen können. Die Vorderseite des Voice Switch zeigt nach rechts, wenn das Gerät an der Wand befestigt ist. Dieser Wandmontageträger kann mit den folgenden Geräten verwendet werden:

- Mittel Voice Switch ST50A
- Mittel Voice Switch ST100A
- Mittel Voice Switch ST100DA
- Mittel Voice Switch ST200
- Mittel Voice Switch ST500
- Mittel Voice Switch ST1D
- Mittel Voice Switch ST2D



ACHTUNG: Um ein Überhitzen und Brandgefahr zu verhindern, verwenden Sie nicht den Dual Switch-Rackmontageträger für die Wandmontage von ST Voice Switches.


Installationswerkzeuge und teile

Für die Installation des Mittel Voice Switch benötigen Sie Folgendes:

- Kreuzschlitzschraubenzieher Nr. 1

Vorbereiten einer Sperrholzplatte für den ST Voice Switch-Wandmontageträger


1. Verankern Sie eine Sperrholzplatte sicher an der Wand und der darunterliegenden Struktur.
 - Die mindestens benötigte Wandfläche beträgt 444 mm x 355 mm.
 - Die Mindestgröße der Sperrholzplatte beträgt 368 mm x 279 mm.
 - Die Sperrholzplatte muss mindestens 1/2 inch (13 mm) dick sein.
2. Markieren Sie drei Pilotlöcher mit der Wandaufhängung als Vorlage.
3. An der obersten Markierung, schrauben Sie eine Rundkopf-Holzschraube teilweise in das Sperrholz. Lassen Sie 1/8 inch (3.2 mm) der Schraube vorstehen.



Montage des ST Voice Switch-Wandmontageträgers und Spezifikationen

Vorbereitung der Wand für die Montage des ST Voice Switch-Wandmontageträgers

1. Für die Montage eines ST Voice Switch-Wandmontageträgers wird eine Wandfläche von mindestens 444 mm x 355 mm benötigt.
Mindestdicke der Hohlwand: 10 mm.
Maximaldicke der Hohlwand: 16 mm.
2. Markieren Sie drei Pilotlöcher mit der Wandaufhängung als Vorlage.
3. Setzen Sie Hohlraumdübel bei allen drei Markierungen bündig zur Wand ein.
4. Schrauben Sie eine Kreuzschlitz-Metallschraube teilweise in den Dübel der obersten Position. Lassen Sie 1/8 inch (3.2 mm) der Schraube vorstehen.






Befestigen des ST Voice Switch-Wandmontageträgers an der Wand

1. Hängen Sie den leeren ST Voice-Wandmontageträger an die Schraube an der obersten Position.
2. Ziehen Sie die Schraube fest um den Träger an der Wand zu fixieren.
3. Setzen Sie Metallschrauben in die unteren Positionen ein, um den Träger an der Wand zu sichern.

Einsetzen des ST Voice Switch in den ST Voice Switch-Wandmontageträger

1. Entfernen Sie auf der rechten Seite des ST Voice Switch die Schraube, mit der die obere Abdeckung gesichert ist, wie in der Abbildung rechts gezeigt.
2. Richten Sie die Schlitz auf der linken Seite des Mittel Voice Switch mit den Laschen am Träger aus, schieben Sie die Schlitz des Mittel Voice Switch auf die Laschen des Trägers und setzen Sie den Mittel Voice Switch korrekt in den Träger.
3. Setzen Sie die Schraube für die obere Abdeckung auf der rechten Seite wieder ein, um das Gehäuse sicher am Träger zu befestigen.



Spezifikation des ST Voice Switch-Wandmontageträgers

Feature	Spezifikation
Abmessungen	363 mm x 277 mm x 44 mm
Gewicht	1.23 kg