

## Using Mobility Entry

### Unify OpenScape Business

	DISA phone no. +
Station number dialing	[Stn no.]
Program/delete call forwarding	*11+ [Stn no.] / #1
Do not disturb	*97 / #97
Send message	*68+ [Stn no.] + [code]
Reset all services	#0
CLIR on/off	*86 / #86
-----	
In talk state:	
Up to 16 stations can use features in the talk state.	
Consultation hold	[Stn no. of 2nd stn]
Toggle	*2
Conference	*3
Release and return	*0
Activate callback	*58
DTMF suffix dialing on	*53

Cut out, fold, glue together and keep at hand

## Using Mobility Entry

Mobility Entry allows you to access all of the features provided by your communications platform from your mobile phone or your portable home office phone. If Mobility Entry is activated (contact the responsible service personnel), you can access the same communications platform functions that are available to you at an internal station without having to install additional hardware or software. All you need to do is dial your DISA phone number.

### Caution

Please note that emergency calls cannot be made with Mobility Entry as mobile phones are not recognized. Add-on Mobility Client software can be used on specific mobile phones to further enhance your user experience of Mobility Entry.

For information regarding the availability of this software for your phone, please contact the responsible service personnel.

## FEATURES IN IDLE STATE

### Station number dialing

[Stn no.]  
Dial the DISA phone number and then enter the destination number as the DTMF code[1].

### Program/delete call forwarding

\*11+ [stn no.] or #1  
Dial the DISA phone number, enter the DTMF code and (when programming) the call forwarding destination number[1].

### Activate/deactivate "Do not disturb"

\*97 or #97  
Dial the DISA phone number and enter the DTMF code. This activates/deactivates "Do not disturb" (e.g. close of business, holidays, "private").

# Mobility Entry

## Quick Reference Guide

This Quick Reference Guide will help you get to know the basic functions of your Client. For detailed information on the features of your Client, see the appropriate User Guide and the online help.

A31003-P3000-U100-8-6919

05/2023

mitel.com



## Using Mobility Entry

### Send message

\*68+ [Stn no. of int. stn] + [code 1 - 9]

Dial the DISA phone number and enter the DTMF code. Enter the internal station number and select a number for the message you wish to send. The message is then sent to the internal station.

### Reset all services

#0

Dial the DISA phone number and enter the DTMF code. The following services are reset: Delete all call forwarding and active callback jobs, deactivate "Do not disturb" and "Station number suppression".

### Switch on/off connected line identification restriction (CLIR)

\*86 or #86

Dial the DISA phone number and enter the DTMF code. This suppresses or displays the station number for subsequent calls.

## FEATURES IN TALK STATE / AFTER OUTGOING DIALING

For a maximum of 16 designated stations.

### Consultation hold

[Stn no. of 2nd stn]

Dial the station number of the second station[1]. This initiates consultation hold and puts the first station on hold.

### Toggle

\*2

Enter the DTMF code to switch to the station on hold.

### Conference

\*3

Enter the DTMF code to include multiple stations in a call[2].

## Using Mobility Entry

### Release and return to station on hold

\*0

Enter the DTMF code to end the consultation call. You will then be reconnected with the station on hold[2].

### Activate callback (delete in idle state via #0)

\*58

Enter the DTMF code to activate a callback ("Callback on busy" or "Callback on free"). A callback is requested as soon as the free/busy tone is heard. This is acknowledged by a positive or negative acknowledgement tone (no display).

### Enable DTMF suffix dialing

\*53

Enter the DTMF code. This initiates "transparent" forwarding of the subsequent DTMF code for managing a voicemail system, for example.

[1] When dialing an external destination number, always enter the trunk access code.

[2] Requirement: The call is on consultation hold, see "Consultation hold".

### TIsP:

You can store frequently used functions in the internal phonebook on your mobile phone, for example, so you can access them quickly and conveniently.

To do this, you must enter a "Pause" between the DISA phone number and DTMF code (for example, press and hold \* until "p" appears in the display). For further information, refer to the user manual provided with your mobile phone.

Examples of saved entries:

- +49897221234p0004997214321  
(DISA no. + pause + destination number)
- +49897221234p\*86  
(DISA no. + pause + CLIR on)
- +49897221234p00049894321p\*5399  
(DISA no. + pause + trunk access code + answ. mach. no. + pause + DTMF on + answ. mach. ctrl. "99")